





1. Remove faceplate from lower right corner.



2. Side view of faceplate removal.



3. Pull fabric tab to remove batteries.



4. Completely remove both batteries.
IMPORTANT: DO NOT REPLACE THE BATTERIES

If you notice any signs that your batteries have leaked, please call us.

Residential Customers **1.866.838.6918**
Non-residential Customers **1.866.800.0747**



5. Snap faceplate back into place.